



# XS WIRELESS 1

**Quick Guide** | Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Kort vejledning | Pikaohje | Γρήγορος οδηγός | Kısa Kılavuz | Краткая инструкция | 快速指南 | 快速使用指南 | クイックガイド | 요약 설명서

In the box	Vocal Sets		Instrument Sets		Lavalier Set	Headmic Set
	XSW 1-825	XSW 1-835	XSW 1-C11	XSW 1-908	XSW 1-ME2	XSW 1-ME3
<b>XS WIRELESS 1</b> 	•	•	•	•	•	•
<b>EM-XSW 1</b> 	•	•	•	•	•	•
	•	•	•	•	•	•
	•	•	•	•	•	•
<b>MZQ 1</b> 	•	•	•	•	•	•
	•	•	•	•	•	•
<b>SK-XSW</b> 	•	•	•	•	•	•
<b>e 908T</b> 	•	•	•	•	•	•
<b>ME 2-2</b> 	•	•	•	•	•	•
<b>ME 3-II</b> 	•	•	•	•	•	•
<b>CI 1-N</b> 	•	•	•	•	•	•
<b>2 x AA LR6 1.5 V</b> 	•	•	•	•	•	•

### Battery

- Slide the battery cover open.
- Insert the battery with the correct polarity.
- Slide the battery cover closed.

### Low Battery

Bank 1 Ch. 1  
925.300 MHz

- ~ 10 h
- ~ 7 h
- ~ 3 h
- Low Batt

### Setup

**XLR-3** OR **6.3 mm**

Line Mic

EU US UK AU CN KOR

ME 2-2 e 908T ME 3-II CI 1-N

### On/off

1s on 3s off

OR

OR

### Display

EM-XSW 1

Bank 1...8 Channel 0...9

Sensitivity Sync Low battery

### Volume

0...9

### Mute

Audio on

Audio off

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com  
Printed in Germany, Publ. 02/17, 571312/A02

