



XS WIRELESS 1

Quick Guide | Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Kort vejledning | Pikaohje | Γρήγορος οδηγός | Kısa Kılavuz | Краткая инструкция | 快速指南 | 快速使用指南 | クイックガイド | 요약 설명서

In the box	Vocal Sets		Instrument Sets		Lavalier Set	Headmic Set
	XSW 1-825	XSW 1-835	XSW 1-C11	XSW 1-908	XSW 1-ME2	XSW 1-ME3
XS WIRELESS 1 	•	•	•	•	•	•
EM-XSW 1 	•	•	•	•	•	•
	•	•	•	•	•	•
	•	•	•	•	•	•
MZQ 1 	•	•	•	•	•	•
	•	•	•	•	•	•
SK-XSW 	•	•	•	•	•	•
e 908T 	•	•	•	•	•	•
ME 2-2 	•	•	•	•	•	•
ME 3-II 	•	•	•	•	•	•
CI 1-N 	•	•	•	•	•	•
2 x AA LR6 1.5 V 	•	•	•	•	•	•

Battery

- Slide the battery cover open.
- Insert the battery with the correct polarity.
- Slide the battery cover closed.

Low Battery

Bank 1 Ch. 1
925.300 MHz

- ~ 10 h
- ~ 7 h
- ~ 3 h
- Low Batt

Setup

XLR-3 OR 6.3 mm

Line Mic

EU US UK AU CN KOR

ME 2-2 e 908T ME 3-II CI 1-N

On/off

1s on 3s off

OR

Bank 1 Ch. 1 925.300 MHz

Display

EM-XSW 1

Bank 1...8 Channel 0...9

Sensitivity Sync Low battery

Volume

0...9

Mute






Audio on

Audio off

Sennheiser electronic GmbH & Co. KG






Change frequency

Automatically/Scan



-  Off
-  1. Press Set/Scan (4) → 3s
-  2. Press Set/Scan (4)
-  3. Display shows 23
-  4. Press Set/Scan (4) → Green checkmark



Manually


Bank Channel


-  1. Press Set/Scan (4)
-  2. Press CH+ → Display shows 13
-  3. Press Set/Scan (4)
-  4. Press CH+ → Display shows 23
-  5. Press Set/Scan (4) → Green checkmark


Sync

-  1. Press Set/Scan (4) → hold
-  Press Set/Scan (4) → hold





-  2. Press Sync (1x) → 1x




Sensitivity

Level

0 dB
-10 dB
-20 dB
-30 dB

OR


Multichannel

Bank 1...8
Ch. 0...9

max. 10 ch.


Bank	CH.	Bank	CH.	Bank	CH.	Bank	CH.	
2	3	2	4	2	5	2	6	✓
1	1	1	2	1	3	1	8	✓
2	3	1	3	4	7	8	9	✗
2	3	2	3	2	3	2	3	✗

ME 2-2




25 cm (10")

ME 3-II




2...3 cm (1")

Min. distance




> 5 m (16'5")

SKM



Guitar pickup



> 20 cm (8")

Squelch

min. SQ

max. SQ

